


Sea-Dog Light Tip Toggle Switches #420121 - 420129 Wiring Instructions




420121(-1)

On / Off
Single Pole / Single Throw
Clear Off / Red On

420122(-1)

Mom. On / Off
Single Pole / Single Throw
Clear Off / Red On



420123(-1)


On / Off / On
Single Pole / Double Throw
Clear Off / Red On

420124(-1)

Mom. On / Off / Mom. On
Single Pole / Double Throw
Clear Off / Red On

420125(-1)

Mom. On / Off / On
Single Pole / Double Throw
Clear Off / Red On



420128(-1)

On / Off / On
Double Pole / Double Throw
Clear Off / Red On

420129(-1)

Mom. On / Off / Mom. On
Double Pole / Double Throw
Clear Off / Red On